

ARRIVAL ROUTE DESCRIPTION

FORT WAYNE TRANSITION (FWA.HEDEE1): From over FWA VORTAC via FWA R-128 to OSBER/FWA 22 DME, then via ROD R-134 to ROD VORTAC, then via ROD R-169 to HEDEE INT. Thence. . . .

ROSEWOOD TRANSITION (ROD.HEDEE1): From over ROD VORTAC via ROD R-169 to HEDEE INT. Thence. . . .

. . . .From over HEDEE INT via CVG R-052 (MEA 4,000) to JADAT/CVG 20 DME. Expect radar vectors to final approach course at JADAT.

LOST COMMUNICATION PROCEDURE

In the event of lost communications for:

BUTLER COUNTY RGNL - At JADAT, proceed direct HAMILTON (HAO), maintain 4,000 feet until HAMILTON (HAO).

CINCINNATI MUNI AIRPORT - LUNKEN FIELD - At JADAT, proceed direct MADEIRA (MDE), maintain 4,000 feet until MADEIRA (MDE).

CINCINNATI BLUE ASH - At JADAT, proceed direct BLUE ASH (ISZ), maintain 4,000 feet until BLUE ASH (ISZ).

CLERMONT COUNTY - At JADAT, proceed direct SPORTYS (PWF), maintain 4,000 feet until SPORTYS (PWF).

GENE SNYDER - At JADAT, proceed direct CVG VORTAC then via V517 to FLM VOR/DME, maintain 4,000 feet until FLM VOR/DME.

EC-2, 11 MAR 2010 to 08 APR 2010

EC-2, 11 MAR 2010 to 08 APR 2010