



DEPARTURE ROUTE DESCRIPTION

When entering controlled airspace, fly assigned heading and altitude to appropriate route.

JETS

Jets requesting 17,000 and below expect GARLAND Departure.

BELCHER TRANSITION (DALL9.EIC): (For aircraft inbound to the JAN, MLU and SHV terminal areas only.) From over TTT VOR/DME via TTT R-094 to POTEN INT, then via EIC R-259 to EIC VORTAC.

EL DORADO TRANSITION (DALL9.ELD): (For aircraft inbound to the Memphis Terminal area. Aircraft should file and/or expect appropriate STAR.) From over TTT VOR/DME via TTT R-084 to SOLDO INT, then via UIM R-261 to UIM VOR/DME, then via UIM R-072 and ELD R-254 to ELD VORTAC.

LITTLE ROCK TRANSITION (DALL9.LIT): From over TTT VOR/DME via TTT R-064 to ORTRO INT, then via LIT R-235 to LIT VORTAC.

MERIDIAN TRANSITION (DALL9.MEI): (For aircraft inbound to the Atlanta Terminal area.) From over TTT VOR/DME via TTT R-084 to SOLDO INT, then via UIM R-261 to UIM VOR/DME, then via UIM R-072 and ELD R-254 to ELD VORTAC, then via ELD R-097 and MEI R-281 to MEI VORTAC.

QUITMAN TRANSITION (DALL9.UIM): (For aircraft inbound to Shreveport Terminal area.) From over TTT VOR/DME via TTT R-084 to SOLDO INT, then via UIM R-261 to UIM VOR/DME.

SAWMILL TRANSITION (DALL9.SWB): From over TTT VOR/DME via TTT R-094 to POTEN INT, then via EIC R-259 to TEKBE INT, then via SWB R-291 to SWB VOR/DME.

SIDON TRANSITION (DALL9.SQS): From over TTT VOR/DME via TTT R-084 to SOLDO INT, then via UIM R-261 to UIM VOR/DME, then via UIM R-072 and ELD R-254 to ELD VORTAC, then via ELD R-077 and SQS R-262 to SQS VORTAC.

SOLDO TRANSITION (DALL9.SOLDO): From over TTT VOR/DME via TTT R-084 to SOLDO INT.

TEXARKANA TRANSITION (DALL9.TXK): From over TTT VOR/DME via TTT R-074 to SHERO INT, then via TXK R-244 to TXK VORTAC.

SC-2, 11 MAR 2010 to 08 APR 2010

SC-2, 11 MAR 2010 to 08 APR 2010