



DEPARTURE ROUTE DESCRIPTION

TAKE-OFF RUNWAY 14: Climbing right turn direct to MEF NDB, depart MEF NDB 063° bearing outbound to BRUTE INT. Thence. . . .

TAKE-OFF RUNWAY 32: Climbing right turn via 060° heading and OED R-098 to BRUTE INT. Thence. . . .

. . . . via (transition) or (assigned route). Maintain 11000 or assigned altitude.

COPPO TRANSITION (BRUTE5.COPPO) : From over BRUTE INT via OED R-098 to LANKS INT. Turn right and proceed via the OED 15 DME Arc to COPPO DME.

CUTTR TRANSITION (BRUTE5.CUTTR) : From over BRUTE INT via MEF NDB bearing 063° to CEROS INT. Turn left and proceed via the OED 15 DME Arc to CUTTR DME.

DREWS TRANSITION (BRUTE5.DREWS) : From over BRUTE INT via MEF NDB bearing 063° to CEROS INT. Turn left and proceed via the OED 15 DME Arc to DREWS DME.

GRENA TRANSITION (BRUTE5.GRENA) : From over BRUTE INT via OED R-098 to LANKS INT. Turn right and proceed via the OED 15 DME Arc to JADUN DME. Then via OED R-138 to GRENA INT.

HANDY TRANSITION (BRUTE5.HANDY) : From over BRUTE INT via OED R-098 to LANKS INT. Turn right and proceed via the OED 15 DME Arc to HANDY DME.

LANKS TRANSITION (BRUTE5.LANKS) : From over BRUTE INT via OED R-098 to LANKS INT.

MOURN TRANSITION (BRUTE5.MOURN) : From over BRUTE INT via MEF NDB bearing 063° to CEROS INT. Turn left and proceed via the OED 15 DME Arc to UZEHE DME. Then via OED R-333 to MOURN INT.

TALEM TRANSITION (BRUTE5.TALEM) : From over BRUTE INT via OED R-098 to LANKS INT. Turn right and proceed via the OED 15 DME Arc to FIBUR DME. Then via OED R-157 to TALEM DME.

UZEHE TRANSITION (BRUTE5.UZEHE) : From over BRUTE INT via MEF NDB bearing 063° to CEROS INT. Turn left and proceed via the OED 15 DME Arc to UZEHE DME.

NW-1, 19 NOV 2009 to 17 DEC 2009

NW-1, 19 NOV 2009 to 17 DEC 2009