



## DEPARTURE ROUTE DESCRIPTION

When entering controlled airspace fly assigned heading and altitude to appropriate route.

ARDMORE TRANSITION (TEX1.ADM): From over FUZ VORTAC via FUZ R-348 to LOWGN INT, then via ADM R-179 to ADM VORTAC.

BLECO TRANSITION (TEX1.BLECO): (ATC assigned.) From over FUZ VORTAC via FUZ R-360 to BLECO INT.

EAKER TRANSITION (TEX1.EAKER): (For aircraft inbound to the Tulsa terminal area.) From over FUZ VORTAC via FUZ R-012 to EAKER INT.

GRABE TRANSITION (TEX1.GRABE): (ATC assigned.) From over FUZ VORTAC via FUZ R-012 to GRABE INT.

MCALESTER TRANSITION (TEX1.MLC): (For all aircraft overflying the MLC VORTAC or intercepting J105.) From over FUZ VORTAC via FUZ R-022 to TIKYS INT, then via MLC R-206 to MLC VORTAC.

OKMULGEE TRANSITION (TEX1.OKM): (For all aircraft overflying OKM VOR/DME proceeding via J181 to BDF to destinations in the Chicago terminal area and north.) From over FUZ VORTAC via FUZ R-012 to EAKER INT, then via OKM R-196 to OKM VOR/DME.

ROLLS TRANSITION (TEX1.ROLLS): (For all aircraft proceeding northwestbound via J52.) From over FUZ VORTAC via FUZ R-348 to LOWGN INT, then via ADM R-179 to ADM VORTAC, then via ADM R-303 to ROLLS INT.

TULSA TRANSITION (TEX1.TUL): (For all aircraft overflying TUL VORTAC.) From over FUZ VORTAC via FUZ R-360 to ZEMMA INT, then via TUL R-201 to TUL VORTAC.

WILL ROGERS TRANSITION (TEX1.IRW): (For all aircraft inbound to the Oklahoma City area or overflying IRW VORTAC.) From over FUZ VORTAC via FUZ R-360 to ZEMMA INT, then via IRW R-145 to IRW VORTAC.

ZEMMA TRANSITION (TEX1.ZEMMA): (ATC assigned.) From over FUZ VORTAC via FUZ R-360 to ZEMMA INT.